

1. Remove the four lower foot pads,



2. Unscrewing the 4 screws,



3. You Need a card, a little hard pressed down, and then around a circle, you can open



4. Open the box, and you can see the battery inside,



5. Unplug the battery and wait two minutes before inserting it.



6. Short the battery socket two pins for more than 5 seconds

